


*4K—BUTTER DISH
6.00



5.00
4F—10" PLATE
4G—7" PLATE 3.00
4E—5" SAUCER 2.50



*5CC—5 OZ. TEACUP — 2.50



*4X—14 OZ. CEREAL
3.00



*5L—12 OZ.
TUMBLER
3.50



*5LC—6 OZ.
JUICE
3.00



4C—CUP
3.00



*4Y—6" SPOON HOLDER
3.00



*4H—SALT & PEPPER
4.25



*4SC—11 OZ. SOUP CUP
3.50



8.50 *4V—2 QT. BAKER/BEAN POT
15.00 *4V/W—BAKER/W WARMER SET



4A—8 OZ. CREAMER
3.00



4B—SUGAR WITH LID
4.50



*4M—18 OZ. MUG
4.00

4AB—CREAM & SUGAR SET
7.00



*4N—24 OZ. VEGETABLE
4.25



*4P—13" PLATTER
7.00



*M2—18 OZ. STEIN
4.00



*224—8" ROUND BOWL
6.00



*4W—3 QT. BAKER/BEAN POT — 12.00
*4W/W—BAKER/W WARMER SET — 18.50



*4QD—11" DIVIDED BOWL
7.00



*201—9" BOWL — 4.25



*242
CORN DISH
2.50



*XO—3 OZ.
SINGLE SERVING BOWL
1.50



*BP—6 OZ. BEAN POT
OR CUSTARD
2.50



*4XL—24 OZ. SALAD
OR GUMBO
3.50



*243—BONE DISH—6½"
2.50



*244—INDIVIDUAL
VEGETABLE BOWL—2.50



*4D—2 QT. PITCHER
8.50

THIS PAGE AVAILABLE IN PRAIRIE GREEN, DESERT GOLD, BROWN SATIN AND ROBIN EGG BLUE, EXCEPT WHERE NOTED*

*AVAILABLE IN ALL COLORS — ADD 50% FOR FLAME

Dinnerware Not Available in Terra Cotta.

SIZES ARE APPROXIMATE AND MAY VARY SLIGHTLY.